



Map S3t-27

Horizontal datum: GDA94
 Projection: UTM (MGA Zone 55)
 Prepared 3 February 2022
 Maritime Safety Queensland
 Spatial Services

PORT PROCEDURES MANUAL

PORT OF ABBOT POINT

**Pilot Boarding Ground and Pilot Disembarking Place
 DEPARTURE ROUTE**

Harbour Master's Direction (HMD)

Departing vessels must proceed east after dropping pilot at PDP (WP1) and transit around the anchorage from:

WP1 PDP 19° 48.500' S; 148° 06.900' E to
 WP2 TWR 19° 48.500' S; 148° 15.000' E
 Then north to the TWR (Two Way Route) if using Palm Passage, or
 in a south easterly direction along the TWR if proceeding south.

© The State of Queensland 2022
 (Transport and Main Roads)

